

Stop Assist

Grain trailer alignment made simple. Create a repeatable stopping point for loading and unloading with clear visual and audible alerts. Move the Stop Assist wherever it is needed or use it at a permanent installation. Additional reflector/indicators allow multiple trucks or trailers to use the same main unit.



APPLICATIONS

The Stop Assist helps operators create a clear, repeatable stopping point anywhere vehicles must align with loading or unloading equipment. Common uses include:

- Grain pits and receiving stations
- Grain augers and conveyors
- Feed trucks and feed trailers
- Seed tenders and fertilizer equipment
- Railcar loading and unloading
- Cement and aggregate operations
- Construction-site loading areas
- Any operation requiring consistent vehicle positioning

FEATURES & BENEFITS

- Establishes a consistent stopping point
- Helps reduce repositioning, delays and spills
- Provides visual and audible confirmation
- Top-mounted LED work light provides added visibility for setup and operation after sunset
- Includes two rechargeable batteries and a 120 VAC charger that plugs into the side of the unit—no battery removal required
- Helps eliminate the need for a dedicated spotter
- Helps keep trucks moving during busy periods

HOW IT WORKS

- 1. Line it up** – Position the truck or trailer.
- 2. Lock in the position** – Place the Stop Assist main unit beside the vehicle, then attach the reflector/indicator to the truck or trailer.
- 3. Repeat the perfect stop** – On every return trip, follow the visual and audible alerts to reach the same stopping point quickly and confidently.



LEARN MORE

